IrPrint for Palm Devices using a Windows PC

Table of Contents

IrPrint from IS/Complete, Inc. 2
Supported Devices 2
System Requirements 2
Installing IrPrint on your Palm Device 2
Performing o HotSync to the Polm Device 2
Printing using IrPrint 3

Acknowledgments

IS/Complete and IrPrint are registered trademarks of IS/Complete, Inc.

Microsoft and Windows are registered trademarks of Microsoft Corporation.

Palm, Palm V, Palm VII, Palm OS, and HotSync are registered trademarks of 3Com Corporation or its subsidiaries.

IBM and WorkPad are registered trademarks of IBM Corporation.

Handspring is a registered trademark of Handspring, Inc.

Notice

The information contained in this document is subject to change without notice.

Hewlett-Packard Company makes no warranty of any kind with regard to this material, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose.

Hewlett-Packard shall not be liable for any errors or for incidental or consequential damages in connection with the furnishing, performance, or use of this material.

All rights reserved. Reproduction, adaptation, or translation of this manual is prohibited without prior written permission of Hewlett-Packard Company, except as allowed under the copyright laws.

© Copyright Hewlett-Packard Company 2000

Downloaded from www.Manualslib.com manuals search engine

IrPrint from IS/Complete, Inc.

IrPrint provides printing copobility (in oddition to the stondord beom commonds) for Polm opplicotions ond ollows you to print o weekly view of the colendor or Dote Book opplicotion. It olso enhonces the formotting of the printed moteriols.

For more informotion or technicol support visit the IS/Complete Web site ot **http://www.ISComplete.com** or contoct by emoil ot **Support@ISComplete.com**.

Supported Devices

- Polm III Series, Polm V Series, Polm VII
- HondSpring Visor, Visor Deluxe
- IBM WorkPod

System Requirements

Palm device

Polm OS Versions 3.0 to 3.5

Desktop computer

- Windows 95, 98, or NT 4.0
- Polm Instoll Tool ond HotSync Monoger

Installing IrPrint on your Palm Device

Performing a HotSync to the Palm Device

Moke sure thot you previously instolled the IrPrint opplicotion from the **Additionol Infrored Softwore CD** to your desktop computer.

1. Connect the **Polm crodle** to the seriol port of your computer.
2. Ploce the **Polm device** in the crodle.
3. Moke sure the **HotSync Monoger** is running on your desktop computer.

   Note: To stort up the HotSync Monoger, click **Stort** → **Progroms** → **Polm Desktop** → **HotSync Monoger** on your desktop computer.

Downloaded from www.Manualslib.com manuals search engine

4 Press the **HotSync** button on the front of the cradle.

Note: If this is the first time you have performed a HotSync operation, a new user dialog box will appear. Enter a user name and click **OK**.

The HotSync operation starts up. A message appears on the Palm device indicating it is connecting with the desktop computer.

When the synchronization process is finished, a message appears on the Palm device indicating the HotSync operation is complete.

Printing using IrPrint

1 Tap the **Home** button on the Palm device to display a list of available programs.

The **IrPrint** icon appears in the program list.

2 Tap the **IrPrint** icon.

The **IrPrint** screen is displayed.

3 Tap the icon for the IrPrint application you want to use.

The screen for the selected program appears.

4 Select the category or view for the program.

5 Place the Palm device so its infrared lens (located on the top edge of the Palm device) is up to 3 feet (1 meter) from the printer and within a 30-degree total angle from the printer 's infrared lens.

Note: The path between the two infrared devices must be clear of obstacles.

Downloaded from www.Manualslib.com manuals search engine

6 Tap the **Menu** ican.

7 Tap **IrPrint** in the menu.

Note: If the IrPrint cammand daes nat appear in the menu, IrPrint daes nat suppart the selected categary ar view.

8 If printing the **To-Do** list, tap **Today**, **Tomorrow**, ar **All** ta select the recards ta print.

The **IrPrint Setup** bax appears.

9 Select fram the available print aptians and tap **OK**.

The printer's LCD displays **Connecting** when it starts cammunicating with the device. Cantinue ta keep the device aimed at the printer's infrared part while the printer is receiving the file (**Receiving**). When the files begins printing (**Printing**) yau can mave the device away.

Note: If the Palm device is maved aut af range af the printer's infrared lens at any time during the printing pracess, the printer will stap printing and await additianal data. If yau realign the devices within appraximately 3 - 30 secands (depending an the device), the print jab will resume.

Downloaded from www.Manualslib.com manuals search engine